

HOW TO INSTALL: TOYOTA TACOMA FUEL TANK SKID PLATE



Step 1



If you have a TRD Off-Road, remove the (4) nuts that hold on your factory gas tank skid with a 12mm socket. Remove the factory skid.

Step 2



Using a floor jack or a friend, lift the skid plate into position and put the threaded studs through the (4) holes on the skid.

Step 3



Re-install the (4) nuts.

Step 4



If you do NOT have TRD Tank Straps. Use a floor jack and put pressure on the gas tank to hold it in place. Remove the 12MM bolt holding the strap.

Step 5



Then allow the strap to fall down. Remove the cotter pin on the other side, then remove the $\frac{3}{4}$ " pin that holds the strap in place.

Step 6



Take the strap off and replace with your new one, following these steps in reverse order.